



# WARNING! FOR YOUR SAFETY!

GUIDES AND INSTRUCTIONS TO PREVENT DAMAGE AND/OR INJURY USING A FIRE RING OR PIT | Rev. 08/11/23

- This unit is for outdoor use only, and shall **NOT** be used in any building, garage, or other enclosed area.
- Do **NOT** use this outdoor fire pit for indoor heating. Carbon Monoxide TOXIC fumes can accumulate and cause asphyxiation.
- This outdoor fire pit is **NOT** to be used for commercial use.
- This outdoor fire pit is **NOT** to be started, stirred, or loaded by children.
- This outdoor fire pit is **NOT** to be used in or on boats, recreational vehicles, or any other vehicles.
- Always use in accordance with all applicable local, state, and national codes. Contact your local fire department for details on outdoor burning to see if you are violating any laws or codes.
- When using this outdoor fire pit, use the same precautions you would with any open fire.
- The use of alcohol, non-prescription or prescription drugs may impair the consumer's ability to properly assemble or safely operate this outdoor fire pit.
- Use with dry, seasoned hardwood in your fire pit. It will create less smoke, create more heat, and the logs will burn more completely.
- Do **NOT** burn charcoal briquet's, lump charcoal, manufactured logs, driftwood, trash, leaves, paper, cardboard, plywood, painted or stained or pressure treated wood. Avoid using softwoods such as pine or cedar that can throw sparks.
- Do **NOT** alter this fire pit in any manner.
- Do **NOT** use this outdoor fire pit until it is COMPLETELY assembled, if applicable, and all parts are securely fastened and tightened.
- Do **NOT** store or use gasoline, kerosene or any other flammable vapors or liquids in the vicinity of this or any other appliance.
- Keep LP gas cylinders at least 10 feet away from this outdoor fire pit while it is in operation.
- Do **NOT** use this outdoor fire pit near any type of vehicles.
- Keep outdoor fire pit area clear and free from combustible materials, gasoline, and other flammable liquids.
- **DON'T** use this outdoor fire pit under any overhead or near any unprotected combustible constructions. Do **NOT** use fire pit under overhanging trees and shrubs.
- Always use this outdoor fire pit on a hard, level non-combustible surface such a concrete, rock, or stone. Avoid using fire pit on asphalt, blacktop surface, or on wooden decks.
- Remember to always empty this outdoor fire pit before each use. Leave a thin layer of ash to protect the bottom.

CONTINUE ON TO PAGE 2

- Be aware of your clothing. Do not wear flammable or loose clothing when operating this outdoor fire pit.
- Fire pit is **NOT** to be used in windy conditions.
- **NEVER** use gasoline, kerosene, diesel fuel, lighter fluid or alcohol to light or relight fires.
- Electrical cords should be kept away from a hot fire pit.
- The entire surface of this outdoor fire pit will be hot when in operation. Do **NOT** touch fire pit until it has completely cooled unless you are wearing protective gear (Potholders, gloves, BBQ mittens, hot pads & etc.). No one should EVER touch ashes or coals to see if they are hot.
- **NEVER** leave a lit outdoor fire pit unattended. Be wary of children and pets around fire pit.
- **NEVER** move or store this outdoor fire pit until all ashes and coals are completely extinguished.
- Do **NOT** remove ashes or coals until they are completely and fully extinguished.
- Use heat-resistant gloves or hot pads when contacting handles.
- Do **NOT** add or move logs unless you have long, sturdy fire pit tools.
- **NEVER** overload the fire pit. **NEVER** add additional firewood until the fire burns down.  
NOTICE: If any portion of this outdoor fire pit are glowing red, it is overloaded.
- Do **NOT** lean over this fire pit when lighting or when in use.
- Do **NOT** place hot fire pit tools onto combustible surfaces such as grass, wooden deck, or furniture.
- Do **NOT** breathe smoke from the fire and try to avoid getting smoke into your eyes.
- Your outdoor fire pit should be thoroughly inspected and cleaned on a regular basis.
- If outdoor fire pit has been in storage or not used for a long period of time operator needs to check for signs of damage and creosote build-up. Make necessary repairs and/or cleanup before fire pit is used.
- Please use common sense!! Deaths, serious injury or damage to property may occur if the above is not followed exactly.